



PREPARATION

Be sure roof to be coated is swept clean. All repairs should be done before application of Poly-S.

APPLICATION

Spray, brush or squeegee adhesive coating on roof and before coating begins to cure, roll out Poly-S and imbed into coating. Then top coat with roof coating. Remember to lap accordingly: 3" side lap and 6" end lap. It may be necessary to brush polyester mat to ensure complete adhesion.

NOTE: This material is part of the ALCO CAP Roof system (New Roof, Roof Maintenance and Metal-Ply Roof). Call your sales representative for further information.

SPECIFICATION

3 Oz/Square Yard

PACKAGING

40" X 324 LF Roll 25/Pallet

FOR FURTHER SAFETY INFORMATION SEE MSDS REGARDING THIS PRODUCT

Alco Products, LLC

580 St. Jean
Detroit, Michigan 48214

Online: www.alco-products.com

Local: 313.823.7500
Fax: 313.331.4726
Toll Free: 800.323.0029

Email: info@alco-products.com



Your Second Line of Defense™